

How to enable the new functions on your device:

Update the firmware with the NOXON Manager software. Follow the instructions below to download it from our website. You will also need the current firmware version, which is contained in the downloaded file. Next, ensure that the NOXON is on the same network as the computer from which you will be applying the update. You will most likely only have one network at home; in a business setting, please contact your system administrator. Windows XP (32Bit) or Windows 2000 are required. Windows XP (64Bit) and Windows Vista are currently not supported.

Important note!



The update will discard all of your previous settings. After the update, you will need to set up your network connection and rebuild your Favorites menu. Please write down the network settings in the configuration menu and your Favorites for use after the update.





Favorites and radio stations that have been stored via www.radio567.com and which are available via the "Internet Radio" option of the main menu will not be lost.

Overview of the installation:



- 1. Download and unzip NOXON Manager and firmware package**
- 2. Install the NOXON Manager**
- 3. Apply the update via the network with the NOXON Manager**




1. Download and unzip NOXON Manager and firmware package

Steps	Image (Examples)	Description
1. Download the NOXON Manager and firmware package from our website.		Please visit our website at http://www.terratec.com You can find the package under "Support" → "Driver" → "Home Entertainment" → YOUR DEVICE Click to download and store the file on your PC.
2. Double-click the downloaded file		The file is still zipped (compressed in a "zip" archive for faster downloading) and must be unzipped before use. Simply double-click the file.

3. Click "OK".		A message will be displayed, indicating that the file is a self-extracting archive.
4. Click "Unzip".		To unpack the file, simply click "Unzip". Select a location on your hard drive for the unzipped files. Be sure to make a note of the path!
5. Click "OK".		A message will appear, indicating that 6 files were unzipped successfully.
6. Double-click the unzipped "Setup.exe" file to run it.		If you did not change the path in Step 4, you will find all the files you need for the update at C:\TerraTec\NOXON — select your device here. The file setup.exe is located in the NOXON Manager subfolder. Double-click the file to run it.




2. Installing the NOXON Manager





Steps	Image	Description
1. Click "Next" to continue.		A welcome screen will appear containing the warning to close all other programs during the installation. Please check that they are all closed.
2. Accept license agreement and click "Next".		Accept the license agreement to continue with the installation.

3. Enter an installation path or accept the default and click "Next".		Enter a folder on your hard drive in which you would like to install the program. If you do not specify a path, the software will be installed in the default location at C:\Program Files\.
4. Click "Next" to start the actual installation.		One last confirmation before the files are copied.
6. Complete the installation with "Finish".		The installation has now been completed successfully.

3. Apply the update via the network with the NOXON Manager

Note: to upgrade your NOXON, it and your PC must be on the same network. In normal home settings, this will be the case automatically. If you are on a business network, please contact your system administrator. The NOXON must be switched on.

Steps	Image	Description
1. Start the NOXON Manager on your PC.		By default, the NOXON Manager is located at C:\Program Files\TerraTec NOXON audio Manager\.
2. Select your NOXON model from the list and click "Firmware...".		All NOXON devices connected to your network are listed here. Note: Be sure to choose the correct NOXON. If you did not turn on your NOXON until after you launched the NOXON Manager, click the "Discover" button again to scan your network for it.
3. Click "Next" to continue.		Check the status of the selected NOXON here.

4. Select the downloaded firmware file and click "Open".		Select the required firmware file. By default, it is located at C:\TerraTec\NOXON\Firmware 3.5 Note: Please ensure that you have downloaded and selected the correct firmware for your NOXON. Incorrect firmware could damage your device.
6. Check one last time that you have the correct firmware and click "Next>".		The update process will now begin.
7. Please be patient.		Loading the firmware may take time. Please be patient... Note: take care not to switch your NOXON off, use it, unplug it, or disconnect it from the network until the firmware update is complete.
8. To complete the update, click "Finish".		The firmware update is now successfully installed on your NOXON. The NOXON should now be powered up and ready.